Technical Datasheet



Venus V-999

Reusable Full Face Mask – Silicone / TPE



VENUS V-999 Full Face Mask Compatible with Venus V-7900 dual Filters

Item #	Colour	Size
110355401	GREY	MEDIUM - SILICON - AF
110534201	GREY	MEDIUM-TPE
110534701	GREY	MEDIUM - TPE ANTIFOG

VENUS V-999 Full Face Mask Compatible with Venus V-7700 Single Filters

U			
ltem #	Colour	Size	
110543601	GREY	MEDIUM-TPE - with Speech	
		enhancer	

Technical Specifications:

- 1. **Material**: High-quality Thermo Plastic Elastomer (TPE) or Silicone.
- 2. Size Options: Available in small, medium, and large.
- 3. Weight: Approximately 390 gm (TPE) and 462 gm (Silicone).
- 4. Shelf Life: 60 months when stored under recommended conditions.
- 5. Accessories: Includes spare parts and reusable storage box.

Features of Venus V-999 Full Face Mask:

- 1. Twist N Click Mechanism: Quick and secure filter attachment with Venus V-7900 dual filters.
- 2. Ergonomic Design: Zero-power toric visor for wide vision and anti-fog impact-resistant PC lens.
- 3. Advanced Ventilation and Silicone Exhalation Valve: Efficient ventilation system with a highperformance exhalation valve.
- 4. Skin-Friendly Materials: Facepiece made from silicone or TPE for comfort and durability.
- 5. Adjustable Harness and Penta Belt: 4-point harness and adjustable penta belt for secure fit and balanced weight distribution.
- 6. Speech Enhancer Holder: Integrated Speech Enhancer Holder.
- 7. Lightweight Construction: Available in two weight options (TPE: 390 gm, Silicone: 462 gm).
- 8. **Drop-Down and Lock Down Mechanisms:** Easy donning and doffing without removing other PPE, along with a secure head cradle mechanism.
- 9. Replaceable Filters: Compatible with a variety of gas and particle filters.
- 10. Durable Storage: Comes with a reusable storage box.
- 11. Certified Standards: Compliance with IS 14166:2014, IS 15322, and IS 15323 safety standards.







Benefits of Venus V-999 Full Face Mask:

- 1. **Twist N Click Mechanism:** Saves time during filter replacement and ensures proper attachment for safety and reliability.
- **2. Ergonomic Design:** Enhances user visibility in challenging environments, reducing accidents and increasing efficiency.
- **3.** Advanced Ventilation and Silicone Exhalation Valve: Improves comfort during extended wear by reducing heat and moisture build-up, making it suitable for long-duration tasks.
- 4. **Skin-Friendly Material:** Reduces irritation, ensuring user comfort and compliance, especially during prolonged use.
- 5. Adjustable Harness and Penta Belt: 4-point harness and adjustable penta belt for secure fit and balanced weight distribution.
- 6. Speech Enhancer Holder: Allows clear communication without removing the mask, essential for team operations in industrial settings.
- 7. Lightweight Construction: Minimizes strain on the wearer, making it easier to use during extended work hours.
- 8. **Drop-Down and Lock Down Mechanisms:** Facilitates quick adjustments and ensures a reliable fit, reducing interruptions and improving workflow.
- 9. **Replaceable Filters:** Offers cost-effective protection by enabling filter replacement instead of full mask replacement.
- **10. Durable Storage:** Protects the mask during storage and transport, extending its service life.
- **11. Certified Standards:** Assures reliable protection in hazardous environments, ensuring user safety and regulatory compliance.

Cautions & Limitations for Venus V-999 Full Face Mask:

- 1. **Proper Training Required**: Must be used by trained personnel in accordance with safety standards.
- 2. Not for Oxygen Deficiency: Do not use in atmospheres with less than 17% oxygen or unknown contaminants.
- 3. **Filter Suitability**: Ensure the correct filter type is used for specific hazards; gas filters don't protect against particles, and vice versa.
- 4. No Modifications: Do not alter or modify the respirator.
- 5. Facial Seal Integrity: Avoid use with beards or facial hair that can compromise the seal.
- 6. **Damage or Difficulty**: Replace immediately if damaged, breathing becomes difficult, or signs of dizziness occur.
- 7. Explosive Atmospheres: Follow special instructions when used in explosive conditions.
- 8. **Filter Replacement**: Replace gas filters upon detecting odor, taste, or irritation; replace particle filters when breathing resistance increases.
- 9. Disposal: Dispose of respirator and filters per applicable waste management rules.
- 10. **Storage Conditions**: Store in a sealed pack between -5°C to +50°C with less than 60% humidity.



User Instructions for Venus V-999 Full Face Mask:

- 1. **Training Required**: Wearer must be trained in proper respirator use as per safety standards.
- 2. Hazard Assessment: Use only when contaminants and their concentrations are known.
- 3. Fit and Seal: Ensure a proper fit; avoid use with facial hair or improper adjustments.
- 4. **Breathing Conditions**: Do not use in oxygen-deficient environments (<17%) or with unknown contaminants.
- 5. Filter Use: Always use appropriate filters for specific hazards; replace when resistance increases or odors are detected.
- 6. Damaged Masks: Replace the mask if damaged or breathing becomes difficult.
- 7. Safety Precautions: Do not modify or alter the respirator; leave the area if distress occurs.
- 8. Storage and Disposal: Store in sealed packaging and dispose of as per waste management rules.

Applications for Venus V-999 Full Face Mask:

- 1. Agriculture:
 - Pesticide spraying.
- 2. Automotive:
 - Painting and powder coating.
- 3. Chemical Industries:
 - Laboratory and solvent handling.
- 4. Construction:
 - Dust and particulate protection.
- 5. Pharmaceuticals:
 - Material handling and bulk drugs.
- 6. Petrochemicals:
 - Maintenance and solvent handling.
- 7. Engineering:
 - Welding and painting.
- 8. Mining:
 - Drilling operations.
- 9. Sewage:
 - Tank and drain cleaning.
- 10. Cold Storage:
 - Protection in warehouse environments.

MFG & MKT By:

Venus Safety & Health Pvt. Ltd, Plot No. T-15, Taloja MIDC, Khairane Budruk, Dist-Raigad, Maharashtra, - 410 208, India